

DART AEROSPACE LTD		Work Order: 23833
Description: Start ASS'y		Part Number: D3350-041
Dwg:		Qty: 2
		Page 1 of 1

Step	Location	Procedure	By	Date	Qty
1	DC	Issue Traveller			
1	FP	re powder coat remove any voids in powder coat, smoothly on D3350-041 Batch 22211	ML	05/08/04	2
2	FP	re powder coat as per RS 1004	ML	05/08/04	2
3	QC3	Inspect	CL	05/08/04	2
4	PK	put into stock and identify as D3350-041 Batch 22211	CL	05/08/04	2
5	AC	close w/o 19.54 Job cost Part.	Sut	05.08.09	2
6	DC	inspect Level 21	SP	05/08/04	2

Rev	Date	Change	Revised By	Approved
A		New Issue		